



QR code for Installations Instructions

INSTALLATION INSTRUCTIONS AMBIANE® SP16 PENDANT REMOTE








The unit must be installed by a qualified electrician in accordance with all national and local electrical and construction codes and regulations.













Mounting with Spring clips Adaptor

STEP 1A/B CEILING OPENING




Prepare mounting hole with diameter of 7mm for Standard mounting




Prepare mounting hole with diameter of 91mm for Mounting with Spring clips Adaptor. Thickness of the lower ceiling has to be in range of 10-22mm.

STEP 2A/B CONTROL UNIT MOUNTING



Place control unit above the ceiling.




Mount the control unit to ceiling via two mounting holes and suitable fasteners.

INSTALLATION INSTRUCTIONS AMBIANE® SP16 PENDANT REMOTE



STEP 3A/B PREPARE CONNECTION

1



Shorten power/data cable to required length.


Strip these lengths of cable for wiring connection.

STEP 4A/B PRIMARY POWER CONNECTION

SECONDARY POWER CONNECTION

TERMINAL BLOCK	ov	vcc	
Colour of Wire	Power -	Power +	

Install terminal block to power cable (from Ambiane Power Rack or Ambiane Power AP) and connect it to Primary power socket of the control unit.




STEP 5A/B DATA (DMX OR DALI) AND SECONDARY POWER CABLES CONNECTION

SECONDARY POWER CONNECTION

TERMINAL BLOCK	ov	vcc	
Colour of Wire	Power -	Power +	

DMX CONNECTION

TERMINAL BLOCK	ov	D-	D+
Function	Data Ground	Data -	Data +



Install terminal blocks on SECONDARY POWER and DATA cables and connect them to the control unit.

Set the DIP switches to positions according to your operation mode. The fixture can be controlled by DMX or DALI (switch 11 in OFF position).

STEP 6A LED UNIT CONNECTION


TERMINAL

BLOCK


LED Unit Connection

Α

В



Pull the cable through the hole. Install terminal block on LED unit's cable and connect it to the control unit.



ROBE lighting s. r. o. | Palackeho 416 | 757 01 Valasske Mezirici | Czech Republic | Tel.: +420 571 751 500 | E-mail: info@anolis.eu | www.anolislighting.com

VERSION 2.0 / 12_2023 3


INSTALLATION INSTRUCTIONS






STEP 6B LED UNIT CONNECTION






Pull the cable through the hole. Install terminal block on LED unit's cable and connect it to the control unit.

Connected luminaire before installation.




STEP 7A AMBIANE MOUNTING



Adjust the suspension length, insert the base onto the cable and tighten by the two screws.

NOTE: It is possible to adjust the length using the Hole cover and tighten above the lower ceiling.




Tighten the Hole cover by the setscrew. IMPORTANT! Tighten the setscrew with caution to not damage wires in the cable.

INSTALLATION INSTRUCTIONS **AMBIANE® SP16 PENDANT REMOTE**




STEP 7B **AMBIANE MOUNTING**






Adjust the suspension length and tighten by the two screws and by the one setscrew on Hole cover. IMPORTANT! Tighten the setscrew with caution to not damage wires in the cable.



Lift up spring clips on both sides. Insert luminaire into ceiling opening.

3



Release spring clips to hold lumaire in place.

VERSION 2.0 / 12_2023