





QR code for Installations Instructions




STEP 1 CEILING OPENING




Standard mounting hole with diameter of 100-105mm.



Place control unit above the ceiling through the ceiling opening.



Mount the control unit to ceiling via two mounting holes and suitable fasteners.



Install terminal block to power cable (from Ambiane Power Rack or Ambiane Power HP) and connect it to Primary power socket of the control unit.

ROBE lighting s. r. o. | Palackeho 416 | 757 01 Valasske Mezirici | Czech Republic | Tel.: +420 571 751 500 | E-mail: info@anolis.eu | www.anolislighting.com

Anolis®

.

Black


STEP 4 DATA CABLES CONNECTION (DMX OR DALI)




Install terminal blocks on DMX or DALI data cables and connect them to the control unit.

Set the DIP switches to positions according to your operation mode. The fixture can be controlled by DMX or DALI (switch 11 in OFF position).

STEP 5 SECONDARY POWER CABLE CONNECTION 48V (PSU SCOPE OF OTHERS)




Install terminal block on Secondary power cable and connect it to Secondary power socket of the control unit.



STEP 6 LED UNIT CONNECTION

1

Shorten power/data cable of LED unit to required length.




Strip these lengths of LED unit's cable for wiring connection.

 LED Unit Connection


 TERMINAL BLOCK
 +
 A
 B

 Colour of Wire
 Red
 White
 Blue

4



Install terminal block on LED unit's cable and connect it to the control unit.




LED unit connected to control unit prior to mounting.

ROBE lighting s. r. o. | Palackeho 416 | 757 01 Valasske Mezirici | Czech Republic | Tel.: +420 571 751 500 | E-mail: info@anolis.eu | www.anolislighting.com


Anolis^e

STEP 7 MOUNTING OF LUMINAIRE

1




Spread the holders and tighten them up with Allen key as illustrated.



Insert the fixture into the ceiling mounting hole.

3



Tighten the holders on both sides until the fixture is firmly secured to the ceiling.

ROBE lighting s. r. o. | Palackeho 416 | 757 01 Valasske Mezirici | Czech Republic | Tel.: +420 571 751 500 | E-mail: info@anolis.eu | www.anolislighting.com