





The unit must be installed by a qualified electrician in accordance with all national and local electrical and construction codes and regulations. This device falls under class one and must be grounded!




Eminere with standard mounting brackets.



Brackets spacing.


STEP 1.A MOUNTING AND TILTING - STANDARD BRACKETS

1





The Eminere can be arranged in any orientation on a flat, non-flammable surface by means of two mounting brackets. Two mounting holes can be drilled into the mounting surface according to brackets spacing and size of fasteners, prior to mounting of the fixture.

2




Release locking screw M6x8 on each sides. Position fixture and tighten by screws via brackets holes to pre-drilled holes on the surface. Angle fixture to desired position and tighten locking screw on each sides.

STEP 1.B INSTALLATION WITH WALL-MOUNT BRACKETS




Eminere with longer Mounting Brackets.

1




Undo 2x standard mounting brackets.


2




Install 2x L-shape brackets.




Connect together 2x wall-mount brackets.



Screw in 2x wall-mount brackets to the fixture.





Fixture can be mounted in any orientation on a flat, non-flammable surface. Luminaire can be tilted for easier access to mounting holes (see next step).




Fixture with longer Mounting brackets can be tilted by +105°/-105°. Loosen M6x8 locking screws on both sides, adjust fixture to desired angle (mount fixture to the surface, if it's not done yet) and tighten locking screws on both sides.


STEP 2 CONNECTION




Fixture Input
Connector shown



Fixture Output
Connector shown



Jumper / Leader
Cable





Waterproof cap
Install on last fixture in a row.

CONNECTION OF CABLE AND PANEL CONNECTORS

⚠ Same instalation for Jumper/Leader cable and Waterproof cap. ⚠


LOCK




Please align the arrow symbol and mate the connector. Do NOT rotate the connector. Correct connection should be signalized by silent „click“ sound.

Mating complete.

UNLOCK




Rotate NUT 30 degrees anti-clockwise, same as the arrow direction. (Please do not rotate clockwise during unmating process)




Drop out.

ASSEMBLING OF FIELD INSTALLABLE CONNECTOR

- 1 Dismantle the connector and slide its parts onto the cable (5). Use the seal with inner diameter of 14.5 mm for the Anolis cable. The seal with inner diameter of 14.5 mm serves for cable of diameter 10-14.5mm. The seal with inner diameter of 10 mm serves for cable of diameter 8-10mm.




Sealing nut 4 Seal (inner diameter of 10mm) Seal (inner diameter of 14.5mm) Clamp ring 2 Connector with screws 1




- 2 Remove insulation from the cable (5) and from individual wires and fasten three terminals on data wires.

US color code shown



EU color code shown




- 3** Put parts of the connector on the cable (5) and connect wires to the connector. First connect power wires (L,N, Earth) and after that data wires (D+, D-, 0V). Avoid excessive torsion of data wires!

US color code shown

MALE


FEMALE



EU color code shown

MALE

FEMALE



- 4** After connecting wires to the connector, tighten the three data wires (D+,D-, 0V) by means of the cable binder (6).


- 5** Screw the clamp ring (2) to the connector (1), insert the seal (3) to the clamp ring (2) and tighten the sealing nut (4) enough. During the steps DO NOT TWIST the cable (5).

- 6** Use the same procedure to assemble the connector on the second end of the cable.




6
Cable binder


Do not bend the cable near to the connector, minimum distance for bending is 50mm.




STEP 3 INSTALLATION OF ACCESSORIES - CABLE COVER AND SHIELD




CABLE COVER



SHIELD





Install two sliders on the accessory via two prepared holes and two M4x8 screws. Do not tighten them completely yet.




Slide the accessory into the groove on fixture's side. Center it and tighten the screws completely.


STEP 3 INSTALLATION OF ACCESSORIES - OPTICAL DEMO SET



Optical Foil can be slide in the frame from the side after installation.



Loosen screws on both sides of the Optical Demo Set Frame and slide the Frame on top of the luminaire.



Tighten mounting screws on each side after frame installation. Do not over tighten screws.