




The unit must be installed by a qualified electrician in accordance with all applicable regulations including local and national construction and electrical codes. This device falls under class I and must be grounded!



STEP 1 UNCOVERING OF MOUNTING SLEEVE AND JUNCTION BOX

1


6X  M5x10



Unscrew six M5x10 bolts and remove the Temporary Cover from Mounting Sleeve.

2


4X  M4x20



Unscrew four M4x20 screws and remove the Cover of Junction Box.

3


2X  M4x14



Unscrew two M4x14 screws and release the Junction Box from the Mounting Sleeve for easier access to connection terminals.

STEP 2 CONNECTION - STAND ALONE FIXTURE

1



Shorten the cables according to needs (recommended to 1 m). Connection setup, where every Eminere is independently accepting data from WIFI.

2 Connection – colour coding


Wiring of the Eminere Cable - CE Leader

WIRE	POWER CONNECTION
Brown	L
Blue	N
Green	Ground


Wiring of the Eminere Cable - US Leader

WIRE	POWER CONNECTION
Black	L
White	N
Green	Ground

3 Strip these lengths for cable connections.




4 Wiring connection



STEP 3 CABLE GLAND INSTALLATION


Put cable thru cable gland M20x1.5 and connect into connection terminal. Assemble cable gland as shown below. Use wrench size 24 for cable gland M20x1.5



Apply Loctite 5331 thread sealant on the plastic holder and Loctite 577 thread locking compound on the gland body in the indicated locations prior to assembly.

Failure to properly install cable glands will result in failure of the water tight seal!


STEP 4 FILLING JUNCTION BOX WITH SYNTHETIC RESIN



After checking all connections, fill the junction box with synthetic resin. Make sure that the End cap is inserted in unused cable gland and the earth wire for Cover of Junction Box is pulled out of the junction box before filling it. At filling of the junction box proceed according instructions stated on the bag of the resin. The connection block has to be fully poured in the resin.


STEP 5 CLOSE JUNCTION BOX

1 2X  M4x14



Mount the Junction Box back to Mounting Sleeve and fasten it by two M4x14 screws.


2 4X  2 Nm



Put back the gasket of Junction Box, if it was removed. Connect the grounding wire to the junction box Cover and put the Cover back on Junction Box. Make sure that thread is clean and functional. Fasten the cover with four M4x20 screws.


STEP 6 INSTALLATION OF EMINERE INGROUND

1




Connect the Earth wire of Eminere Inground with the Mounting Sleeve.

2




Insert Eminere Inground into the Mounting Sleeve and fasten it with four M5x25 bolts. Do not use an impact wrench, tighten the screws smoothly with torque of 4Nm.

3





Push down on a small tube, unlocking the tilt adjustment. Hold the tube down, while tilting the Eminere to desired position, and release it to lock the Eminere in position again.




Eminere Inground can be tilted by +15°/-15°.

STEP 7 COVER PLATE INSTALLATION




Install Cover Plate End when fixture doesn't adjoin with another Eminere Inground.




Installation of Cover Plate Support is recommended, especially when Eminere Inground is installed in a loose soil. It is suitable only for those sides of Mounting Sleeves that doesn't adjoin with another Mounting Sleeve.

1

2X  M5x10





Fasten the Cover Plate Support to mounting sleeve (under the cover plate end) by two M5x10 screws with washers and nuts.



Cover Plate Support installed.


STEP 7.A COVER PLATES INSTALLATION - STAND ALONE

1



Insert Cover Plate End on each side of mounting sleeve/top of Eminere Inground.



2



Put Cover Plates Continuous on longer sides of Eminere In-ground/mounting sleeve and fasten it with six M5x30 bolts. Do not use impact wrench. Tighten screws smoothly with torque of 4Nm.

STEP 7.B INSTALLATION OF COVER PLATES - HEAD2HEAD



1 Three types of Cover Plates are necessary for installation of adjoining Eminere Ingrounds



Insert Cover Plate End on each side of Eminere Inground installation (only where is no adjoining Eminere Inground). Insert cover plate middle on top of all adjoining Emineres to cover the gap between them.

Note: Use of Cover Plates Support, under the cover plates end, is recommended for installations in loose soil.

2



Place Cover Plates Continuous on top of Eminere Ingrounds longer sides as illustrated. Make sure that cover plates fit well and fasten them by three M5x30 bolts per Cover Plates Continuous. (total of 12 bolts for installation of two adjoining Eminere Ingrounds 2). Do not use impact wrench. Tighten screws smoothly with torque of 4Nm.